


# Block 1 Enna Boulevard 茵娜大道 第1座

Mechanical and Electrical Provision Plan  
機電裝置平面圖



Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

Staircase Part Plan  
樓梯部分平面圖

G/F Plan 地面層平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位

# Block 1

## Enna Boulevard


### 茵娜大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 1

## Enna Boulevard


### 茵娜大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F Plan 二樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 1

## Enna Boulevard


### 茵娜大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



3/F Plan 三樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 1


## Enna Boulevard

### 茵娜大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



5/F Plan 五樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 1

## Enna Boulevard


### 茵娜大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



R/F Plan 天台平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例


	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS				冷氣機接駁點

# Block 2

## Enna Boulevard

### 茵娜大道 第2座

Mechanical and Electrical Provision Plan  
機電裝置平面圖



Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

Staircase Part Plan  
樓梯部分平面圖

G/F Plan 地面層平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點		IRRIGATION WATER POINT	淋花水龍頭位
	AIR-CONDITIONER POINTS	冷氣機接駁點		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐			

# Block 2

## Enna Boulevard

### 茵娜大道 第2座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			


# Block 2

## Enna Boulevard

### 茵娜大道 第2座

Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F Plan 二樓平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		ELECTRIC WATER HEATER	電熱水爐		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL / U.P. LIGHT FITTING	露台 / 工作平台燈具		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 2

## Enna Boulevard


### 茵娜大道 第2座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



3/F Plan 三樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 2


## Enna Boulevard

### 茵娜大道 第2座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



5/F Plan 五樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN	洗滌盆 / 洗手盆		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 2

## Enna Boulevard


### 茵娜大道 第2座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



R/F Plan 天台平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3

## Enna Boulevard

### 茵娜大道 第3座

Mechanical and Electrical Provision Plan  
機電裝置平面圖



Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

Staircase Part Plan  
樓梯部分平面圖

G/F Plan 地面層平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位

# Block 3

## Enna Boulevard


### 茵娜大道 第3座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 3


## Enna Boulevard

### 茵娜大道 第3座

Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F Plan 二樓平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3

## Enna Boulevard


### 茵娜大道 第3座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



3/F Plan 三樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3


## Enna Boulevard

### 茵娜大道 第3座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



5/F Plan 五樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3

## Enna Boulevard


### 茵娜大道 第3座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



R/F Plan 天台平面圖


0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 1 Ferentino Boulevard 菲利提諾大道 第1座

Mechanical and Electrical Provision Plan  
機電裝置平面圖



Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

Staircase Part Plan  
樓梯部分平面圖

G/F Plan 地面層平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點		IRRIGATION WATER POINT			IRRIGATION WATER POINT	淋花水龍頭點

# Block 1


## Ferentino Boulevard

### 菲利提諾大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 1

## Ferentino Boulevard


### 菲利提諾大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F Plan 二樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 1


## Ferentino Boulevard

### 菲利提諾大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



3/F Plan 三樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 1


## Ferentino Boulevard

### 菲利提諾大道 第1座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



5/F Plan 五樓平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWN GAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 1

## Ferentino Boulevard


### 菲利提諾大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



R/F Plan 天台平面圖


0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 2 Ferentino Boulevard 菲利提諾大道 第2座

Mechanical and Electrical Provision Plan  
機電裝置平面圖



Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

Staircase Part Plan  
樓梯部分平面圖

G/F Plan 地面層平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例


	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位

# Block 2 Ferentino Boulevard 菲利提諾大道 第2座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 2


## Ferentino Boulevard

### 菲利提諾大道 第2座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F Plan 二樓平面圖

0 1 2 3 4 5 6 Metres 米


LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 2

## Ferentino Boulevard


### 菲利提諾大道 第2座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



3/F Plan 三樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 2


## Ferentino Boulevard

### 菲利提諾大道 第2座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



5/F Plan 五樓平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 2


## Ferentino Boulevard

### 菲利提諾大道 第2座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



R/F Plan 天台平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3 Ferentino Boulevard 菲利提諾大道 第3座

## Mechanical and Electrical Provision Plan 機電裝置平面圖


Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

Staircase Part Plan  
樓梯部分平面圖



G/F Plan 地面層平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位


# Block 3 Ferentino Boulevard 菲利提諾大道 第3座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3


## Ferentino Boulevard

### 菲利提諾大道 第3座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F Plan 二樓平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3

## Ferentino Boulevard


### 菲利提諾大道 第3座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



3/F Plan 三樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			


# Block 3 Ferentino Boulevard 菲利提諾大道 第3座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



5/F Plan 五樓平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3

## Ferentino Boulevard


### 菲利提諾大道 第3座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



R/F Plan 天台平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 5 Ferentino Boulevard 菲利提諾大道 第5座

## Mechanical and Electrical Provision Plan 機電裝置平面圖


Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。

Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan Below Planter  
花槽置下部分平面圖

Staircase Part Plan  
樓梯部分平面圖



G/F Plan 地面層平面圖

Part Plan Below Planter  
花槽置下部分平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位

# Block 5


## Ferentino Boulevard

### 菲利提諾大道 第5座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 5

## Ferentino Boulevard


### 菲利提諾大道 第5座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F Plan 二樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 5

## Ferentino Boulevard


### 菲利提諾大道 第5座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



3/F Plan 三樓平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 5

## Ferentino Boulevard


### 菲利提諾大道 第5座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



5/F Plan 五樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN	洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 5


## Ferentino Boulevard

### 菲利提諾大道 第5座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



R/F Plan 天台平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 1 Genova Boulevard 珍諾華大道 第1座

Mechanical and Electrical Provision Plan  
機電裝置平面圖



Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

Staircase Part Plan  
樓梯部分平面圖

G/F Plan 地面層平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例


	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點		IRRIGATION WATER POINT			IRRIGATION WATER POINT	淋花水龍頭位

# Block 1 Genova Boulevard 珍諾華大道 第1座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 1

## Genova Boulevard


### 珍諾華大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F Plan 二樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 1

## Genova Boulevard


### 珍諾華大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



3/F Plan 三樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例


	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 1 Genova Boulevard 珍諾華大道 第1座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



5/F Plan 五樓平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 1

## Genova Boulevard


### 珍諾華大道 第1座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



R/F Plan 天台平面圖


0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 2 Genova Boulevard 珍諾華大道 第2座

Mechanical and Electrical Provision Plan  
機電裝置平面圖



Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

Staircase Part Plan  
樓梯部分平面圖

G/F Plan 地面層平面圖


Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位


# Block 2 Genova Boulevard 珍諾華大道 第2座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米


### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 2


## Genova Boulevard

### 珍諾華大道 第2座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F Plan 二樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 2

## Genova Boulevard


### 珍諾華大道 第2座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



3/F Plan 三樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 2


## Genova Boulevard

### 珍諾華大道 第2座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



5/F Plan 五樓平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN	洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 2

## Genova Boulevard


### 珍諾華大道 第2座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



R/F Plan 天台平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例


	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3 Genova Boulevard 珍諾華大道 第3座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

Staircase Part Plan  
樓梯部分平面圖


G/F Plan 地面層平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例


	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點		IRRIGATION WATER POINT			IRRIGATION WATER POINT	淋花水龍頭位

# Block 3 Genova Boulevard 珍諾華大道 第3座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例


	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 3 Genova Boulevard 珍諾華大道 第3座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F Plan 二樓平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3

## Genova Boulevard


### 珍諾華大道 第3座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



3/F Plan 三樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點


# Block 3 Genova Boulevard 珍諾華大道 第3座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



5/F Plan 五樓平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 3

## Genova Boulevard


### 珍諾華大道 第3座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



R/F Plan 天台平面圖

0 1 2 3 4 5 6 Metres 米


#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS				冷氣機接駁點

# Block 5 Enna Boulevard 茵娜大道 第5座

## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Part Plan of Skylight above  
天窗置上部分平面圖

G/F Plan 地面層平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點		IRRIGATION WATER POINT	淋花水龍頭點
	AIR-CONDITIONER POINTS	冷氣機接駁點		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐			

# Block 5


## Enna Boulevard

### 茵娜大道 第5座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點


# Block 5

## Enna Boulevard

### 茵娜大道 第5座

Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

2/F, 3/F, 5/F -10/F Plan 二樓，三樓，五樓至十樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 5



## Enna Boulevard

### 茵娜大道 第5座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



#### LEGEND 圖例

11/F Plan 十一樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			


# Block 5

## Enna Boulevard

### 茵娜大道 第5座

Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

12/F Plan 十二樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 5

## Enna Boulevard


### 茵娜大道 第5座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

#### Roof Plan 天台平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點


# Block 6

## Enna Boulevard

### 茵娜大道 第6座

#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Part Plan of Skylight above  
天窗置上部分平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

G/F Plan 地面層平面圖



LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位

# Block 6

## Enna Boulevard

### 茵娜大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

1/F Plan 一樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 6


## Enna Boulevard

### 茵娜大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



#### LEGEND 圖例

2/F, 3/F, 5/F -10/F Plan 二樓，三樓，五樓至十樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 6


## Enna Boulevard

### 茵娜大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

11/F Plan 十一樓平面圖

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 6

## Enna Boulevard


### 茵娜大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

#### 12/F Plan 十二樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 6

## Enna Boulevard


### 茵娜大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

#### Roof Plan 天台平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 7


## Enna Boulevard

### 茵娜大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖


Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Part Plan of Skylight above  
天窗置上部分平面圖

G/F Plan 地面層平面圖

Part Plan of Skylight above  
天窗置上部分平面圖



LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位

# Block 7


## Enna Boulevard

### 茵娜大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

1/F Plan 一樓平面圖

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點


# Block 7

## Enna Boulevard

### 茵娜大道 第7座

Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

2/F, 3/F, 5/F -10/F Plan 二樓, 三樓, 五樓至十樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 7

## Enna Boulevard


### 茵娜大道 第7座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

11/F Plan 十一樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			


# Block 7

## Enna Boulevard

### 茵娜大道 第7座

Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



LEGEND 圖例

12/F Plan 十二樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 7

## Enna Boulevard


### 茵娜大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例


#### Roof Plan 天台平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 8 Enna Boulevard 茵娜大道 第8座

## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位



0 1 2 3 4 5 6 Metres 米

# Block 8

## Enna Boulevard

### 茵娜大道 第8座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 8


## Enna Boulevard

### 茵娜大道 第8座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F, 3/F, 5/F -10/F Plan 二樓，三樓，五樓至十樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 8


## Enna Boulevard

### 茵娜大道 第8座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



11/F Plan 十一樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 8


## Enna Boulevard

### 茵娜大道 第8座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



12/F Plan 十二樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 8

## Enna Boulevard


### 茵娜大道 第8座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Roof Plan 天台平面圖

0 1 2 3 4 5 6 Metres 米


#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 6 Ferentino Boulevard 菲利提諾大道 第6座

## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Part Plan of Skylight above  
天窗置上部分平面圖

G/F Plan 地面層平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位

# Block 6


## Ferentino Boulevard

### 菲利提諾大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

#### 1/F Plan 一樓平面圖

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 6


## Ferentino Boulevard

### 菲利提諾大道 第6座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

2/F, 3/F, 5/F -10/F Plan 二樓，三樓，五樓至十樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 6


## Ferentino Boulevard

### 菲利提諾大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

11/F Plan 十一樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 6


## Ferentino Boulevard

### 菲利提諾大道 第6座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

12/F Plan 十二樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 6

## Ferentino Boulevard


### 菲利提諾大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

#### Roof Plan 天台平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點


# Block 7

## Ferentino Boulevard

### 菲利提諾大道 第7座

#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Part Plan of Skylight above  
天窗置上部分平面圖

G/F Plan 地面層平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭點

# Block 7


## Ferentino Boulevard

### 菲利提諾大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

#### 1/F Plan 一樓平面圖

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 7


## Ferentino Boulevard

### 菲利提諾大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

2/F, 3/F, 5/F -10/F Plan 二樓，三樓，五樓至十樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 7



## Ferentino Boulevard

### 菲利提諾大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



#### LEGEND 圖例

11/F Plan 十一樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 7


## Ferentino Boulevard

### 菲利提諾大道 第7座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

12/F Plan 十二樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 7

## Ferentino Boulevard


### 菲利提諾大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

#### Roof Plan 天台平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			


# Block 8 Ferentino Boulevard 菲利提諾大道 第8座

## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Part Plan of Skylight above  
天窗置上部分平面圖



### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配电箱
	1 GANG LIGHTING SWITCH	一位電燈掣
	2 GANG LIGHTING SWITCH	二位電燈掣
	3 GANG LIGHTING SWITCH	三位電燈掣
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆 電熱水爐開關掣
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇 開關掣
	SINGLE SOCKET POWER POINTS	單位電插座
	TWIN SOCKET POWER POINTS	雙位電插座
	WEATHER PROOF SOCKET POWER POINTS	防水電插座
	WATERPROOF WALL LIGHT FITTING	防水牆壁燈具
	KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具
	CEILING LIGHT FITTING	天花燈具
	BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具
	WALL LIGHT FITTING	牆壁燈具
	ELECTRIC WATER HEATER	電熱水爐
	THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐
	VIDEO DOOR PHONE	視像對講機
	TELEPHONE POINTS	電話接駁點
	TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	PANIC BUTTON	求救按鈕
	DOOR BELL PUSH BUTTON	門鈴按鈕
	DOOR BELL	門鈴
	WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點
	IRRIGATION WATER POINT	淋花水龍頭位

Part Plan of Skylight above  
天窗置上部分平面圖

G/F Plan 地面層平面圖

# Block 8

## Ferentino Boulevard


### 菲利提諾大道 第8座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



1/F Plan 一樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 8


## Ferentino Boulevard

### 菲利提諾大道 第8座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



2/F, 3/F, 5/F -10/F Plan 二樓，三樓，五樓至十樓平面圖

0 1 2 3 4 5 6 Metres 米


#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 8


## Ferentino Boulevard

### 菲利提諾大道 第8座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



11/F Plan 十一樓平面圖

0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 8


## Ferentino Boulevard

### 菲利提諾大道 第8座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



12/F Plan 十二樓平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 8

## Ferentino Boulevard


### 菲利提諾大道 第8座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Roof Plan 天台平面圖

0 1 2 3 4 5 6 Metres 米

LEGEND 圖例


	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 5 Genova Boulevard 珍諾華大道 第5座



## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



Part Plan of Skylight above  
天窗置上部分平面圖

G/F Plan 地面層平面圖

Part Plan of Skylight above  
天窗置上部分平面圖

0 1 2 3 4 5 6 Metres 米

### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位

# Block 5

## Genova Boulevard


### 珍諾華大道 第5座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例


#### 1/F Plan 一樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 5 Genova Boulevard 珍諾華大道 第5座

Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

2/F, 3/F, 5/F -10/F Plan 二樓, 三樓, 五樓至十樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 5


## Genova Boulevard

### 珍諾華大道 第5座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

11/F Plan 十一樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 5


## Genova Boulevard

### 珍諾華大道 第5座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

12/F Plan 十二樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS				冷氣機接駁點

# Block 5

## Genova Boulevard


### 珍諾華大道 第5座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例


#### Roof Plan 天台平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 6 Genova Boulevard 珍諾華大道 第6座

## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點					IRRIGATION WATER POINT	淋花水龍頭位

# Block 6

## Genova Boulevard


### 珍諾華大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

#### 1/F Plan 一樓平面圖


	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 6 Genova Boulevard 珍諾華大道 第6座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

2/F, 3/F, 5/F -10/F Plan 二樓，三樓，五樓至十樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 6

## Genova Boulevard


### 珍諾華大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

11/F Plan 十一樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 6


## Genova Boulevard

### 珍諾華大道 第6座



Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

LEGEND 圖例

12/F Plan 十二樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 6

## Genova Boulevard


### 珍諾華大道 第6座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例


#### Roof Plan 天台平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS			AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 7 Genova Boulevard 珍諾華大道 第7座

## Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



### LEGEND 圖例

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	WALL LIGHT FITTING	牆壁燈具		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	AIR-CONDITIONER POINTS	冷氣機接駁點		IRRIGATION WATER POINT			IRRIGATION WATER POINT	淋花水龍頭位

# Block 7

## Genova Boulevard

### 珍諾華大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

1/F Plan 一樓平面圖

	MCB DISTRIBUTION BOARD	配电箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點


# Block 7

## Genova Boulevard

### 珍諾華大道 第7座

Mechanical and Electrical Provision Plan  
機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



LEGEND 圖例

2/F, 3/F, 5/F -10/F Plan 二樓，三樓，五樓至十樓平面圖

0 1 2 3 4 5 6 Metres 米

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS	冷氣機接駁點			

# Block 7

## Genova Boulevard


### 珍諾華大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

#### 11/F Plan 十一樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 7


## Genova Boulevard

### 珍諾華大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.  
請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

12/F Plan 十二樓平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具					AIR-CONDITIONER POINTS	冷氣機接駁點

# Block 7

## Genova Boulevard


### 珍諾華大道 第7座



#### Mechanical and Electrical Provision Plan 機電裝置平面圖

Please refer to pages AL001 to AL004 of this sales brochure for legend of the terms and abbreviations in studying the Mechanical and Electrical Provision Plan of this section.

請參閱本售樓說明書第AL001至AL004頁之圖例以協助解讀此部分的機電裝置平面圖及其顯示之名稱及簡稱。



0 1 2 3 4 5 6 Metres 米

#### LEGEND 圖例

#### Roof Plan 天台平面圖

	MCB DISTRIBUTION BOARD	配電箱		SINGLE SOCKET POWER POINTS	單位電插座		VIDEO DOOR PHONE	視像對講機
	1 GANG LIGHTING SWITCH	一位電燈掣		TWIN SOCKET POWER POINTS	雙位電插座		TELEPHONE POINTS	電話接駁點
	2 GANG LIGHTING SWITCH	二位電燈掣		WEATHER PROOF SOCKET POWER POINTS	防水電插座		TV / FM SOCKET POINTS	電視 / 收音機天線接駁點
	3 GANG LIGHTING SWITCH	三位電燈掣		WATERPROOF WALL LIGHT FITTING	防水牆壁燈具		PANIC BUTTON	求救按鈕
	1 GANG 2 WAY LIGHTING SWITCH	一位二路電燈掣		KITCHEN / BATHROOM LIGHT FITTING	廚房 / 浴室燈具		DOOR BELL PUSH BUTTON	門鈴按鈕
	2 GANG 2 WAY LIGHTING SWITCH	二位二路電燈掣		CEILING LIGHT FITTING	天花燈具		DOOR BELL	門鈴
	3 GANG 2 WAY LIGHTING SWITCH	三位二路電燈掣		BAL. / U.P. LIGHT FITTING	露台 / 工作平台燈具		WATER SUPPLY CONNECTION POINT FOR WASHING MACHINE	洗衣機來水接駁點
	POWER SWITCH FOR SINK / HAND WASH BASIN ELECTRIC WATER HEATER	洗滌盆 / 洗手盆電熱水爐開關掣		ELECTRIC WATER HEATER	電熱水爐		DRAINAGE CONNECTION POINT FOR WASHING MACHINE	洗衣機去水位
	POWER SWITCH FOR ELECTRIC WATER HEATER / EXHAUST FAN	電熱水爐 / 抽氣扇開關掣		THREE-PHASE ELECTRIC WATER HEATER	三相電熱水爐		TOWNGAS CONNECTION POINT FOR GAS COOKER HOB	煤氣煮食爐的煤氣喉接駁點
	WALL LIGHT FITTING	牆壁燈具		AIR-CONDITIONER POINTS				冷氣機接駁點